photokina 2016

Lens Adapters for PL-Mount Cine Lenses

The NOVOFLEX Präzisionstechnik GmbH, Memmingen, belongs to the specialists in the field of lens adapters. There is merely no lens/camera combination for which the Memmingen manufacturer does not offer a suitable adapter within his product range.

On occasion of the photokina 2016 NOVOFLEX will present a series of PL-mount adapters, with which high-quality cine lenses with PL-mount can be used at mirrorless system cameras.

The new PL-adapters have been designed for ambitious, respectively professional videographers who want to use the special features and advantages of their cine lenses also for videos made with mirrorless system cameras. Special features of theses lenses include: stepless aperture control, compatibility with follow focus systems, a special "film look" and – in many cases – a greater focus area for an extremely soft and smooth transition from field to blur etc.

The new adapters offer the possibility to use PL-mount cine lenses with the Leica SL and all mirrorless system cameras with Sony E-mount and MFT-bayonet mount. The exact flange focal length of the adapters can be adjusted by means of supplied shim rings. A ring with 0.1mm thickness is mounted on delivery and rings with the following thicknesses are supplied with each adapter: 1×0.01 mm, 2×0.02 mm, 1×0.05 mm. In addition, the adapters have a permanently mounted tripod foot with an ARCA-compatible dovetail and classic thread sizes with 1/4° and 3/8°.

Camera mount Order code

Leica SL LET/PL
MFT (Micro-Four-Third) MFT/PL
Sony E-Mount NEX/PL

The NOVOFLEX PL-adapters will be available immediately after the photokina 2016.

NOVOFLEX adapters are available for almost any camera/lens combination. For more details please refer to the adapter finder on the NOVOFLEX homepage www.novoflex.de.

For more information please contact: NOVOFLEX Präzisionstechnik GmbH, Brahmsstrasse 7, 87700 Memmingen, Phone +49 83 31 / 8 88 88, Fax +49 83 31 / 4 71 74, E-Mail: mail@novoflex.de or at www.novoflex.de.



Press contact:

Information for the editorial department:

We will be pleased to send you a MBFREE for test purposes.









PL_MOUNT.jpg

PL_MOUNT_Shim.jpg

PL_MOUNT_Leica.jpg



PL_MOUNT_Zeiss.jpg

Information for the editorial department:

Text and photo data can be downloaded from website www.pr-guenther.de (refer to information per company). If desired, we will be pleased to send you the data by e-mail (jg@pr-guenther.de).